

Thank you for choosing these high-quality mills. These mills are a quality product and comply with the acknowledged technical regulations and the law on the safety of appliances.

Important information

This appliance is intended for domestic use only. Improper use, application or insufficient cleaning and care can impair safety and result in danger for the user. cilio cannot accept any responsibility for injuries or damage attributed to improper use.


Safety advice

- Should this device be passed on to other people, make sure that these operating instructions are handed to them along with it.
- Do not expose the mills to weather conditions.
- Do not touch the mills with wet or damp hands.
- Do not place any objects into the grinder.
- Do not press the function button for an extended period, allow the mills to grind in interval steps.

Before the first use

- Read through the operating instructions and safety advice carefully first.
- Remove all packaging material and dispose of it properly.
- Wipe the outside with a soft cloth, slightly moistened if needed. Thoroughly dry off afterwards.

Caution: Do not use any caustic liquids or abrasive cleaning agents.

- Hold the lower part in one hand and gently turn the upper part counter clockwise up to the marking  and lift it off.
- Insert batteries and fill the mills, then put the upper part back over the battery compartment and push until it is placed completely over the lower part.
- The mills are now ready for use. Start grinding by pushing the button on top.

Inserting the batteries

- Open the mill as described above.
- Remove the plastic ring from the battery compartment. Insert 4 batteries (AA 1.5 V) into the battery compartment, respecting the +/- markings. Put the plastic ring back on.
- **Note:** cilio recommends the use of alkaline batteries to prolong the running time and for a brighter light.

Close the mill as described above.

Filling the mill

- Open the mill as described above.
- Remove the battery compartment with a light pull upwards. Fill the mill with peppercorns, coarse salt, dried herbs or spices.
- **Note:** Do not fill completely, but leave a small space.

- Put back the battery compartment onto the lower part by plugging spindle into the intended opening located at the bottom of the battery compartment, then turn it to the locking position.
- Close the mill as described above.
- We recommend storing the mill upright.

Adjusting the grinding degree

- Turn the mill upside down and remove the closing cap.
- The adjusting screw is located at the bottom of the grinding mechanism. Turn the adjusting screw clockwise for a finer grind or a counter clockwise for a coarser grind.
- We recommend 4 turns at the most.

Note: If the amount of ground pepper/salt gradually diminishes, this can have two reasons:

- The batteries are running down. In this case, replace the batteries, the device so that new pepper/salt will fall into the grinder, or refill the device if needed.
- There is insufficient pepper/salt in the mill. In this case, lightly shake the device so that new pepper/salt will fall into the grinder, or refill the device if needed.

Cleaning the mill

- Never immerse the mills in water or other liquids and do not clean them in the dishwasher.
- Wipe the housing with a soft cloth only, slightly moistened if needed.
- Do not use any sharp objects or spirit, solvent, scrubbing brushes or abrasive cleaning agents for cleaning.
- When the grinder is blocked, pour some coarse salt or uncooked rice into your mill and grind it briefly.

Disposal / Recycling



According to the Electric and Electronic Equipment Act (this product may not be disposed of in normal household garbage at the end of its useful life. For this reason, take it to a free communal collection point (e.g. recycling depot) for the recycling of electric and electronic devices. To save the environment, do not throw used batteries into household waste, but hand in the appropriate disposal depots or collection centers.

Guarantee

We cover this device with a guarantee of 2 years from the purchase date. Damages due to normal wear, unauthorized use, improper treatment, incorrect use, lack of care and cleaning, willful destruction, transport or accident, repair by unauthorized persons are excluded from this guarantee. Contact your dealer in case of a guarantee claim. The guarantee can only be honored if the device is accompanied by the sales slip/receipt.

Translations are made in good faith. We do not assume any liability for translation errors. Solely the German text is binding.


cilio

Fabrieksgarantie

Voor dit apparaat verlenen wij een garantie van 2 jaar vanaf aankoopdatum. Van deze garantie uitgesloten is schade die veroorzaakt is door normale slijtage, ondoelmatig gebruik, ondeskundige omgang, verkeerde bediening, gebrek aan onderhoud of reiniging, moedwillige vernieling, transport, een ongeval of ingrepen door personen die hier toe niet gerechtigd zijn. Neem in het geval van garantie contact op met uw leverancier. De garantie kan uitsluitend worden verleend, als de kasbon/rekening bij het apparaat bijgesloten is.

Wij accepteren geen aansprakelijkheid voor contractfouten. Alleen de Duitse tekst blijft bindend.

cilio



PFEFFER- UND SALZMÜHLE
BERGAMO
elektrisch

BEDIENUNGSANLEITUNG AUFBEWAHREN!

© CILIO tech-accessoires GmbH - 03. 2020

cilio tech-accessoires GmbH
Höhscheider Weg 29
42699 Solingen · Germany
www.cilio.de