

## Instructions

# Pivot ATD7 &Tradition 2023


---



Congratulations on your new Pivot lamp, designed in 2023 by &Tradition. We hope that you will enjoy using this product. Please follow these instructions to ensure correct installation. If you have any questions or comments, please do not hesitate to contact us by mail at: [info@andtradition.com](mailto:info@andtradition.com)

&Tradition®

# Pivot ATD7 &Tradition 2023



Please read these instructions carefully and keep them for future reference to ensure the product is used correctly. For your own safety, please read each step of this instruction manual before using the product. &Tradition is not responsible for any faults or damage caused by not following these instructions correctly. Do not modify this product in any way.

## Contents

- A Lamp shade
- B Lamp base with battery compartment
- C LED G4 3W light bulb
- D Magnetic USB cable

## Tools needed

- Screwdriver (for replacing batteries)

## Safety precautions

- Dispose of plastic bag from packaging immediately and keep out of reach of children.
- This lamp is for indoor use only. It can be taken outdoors, but must be kept and stored inside.
- Do not place the USB cable within reach of small children or anywhere there is a risk of it becoming a trip hazard.
- Batteries must be disposed of according to local environmental laws for waste disposal.
- Consult a professionally qualified electrician if in any doubt.
- Keep product out of reach of children.

## Cleaning instructions

- Wipe surface of the shade with a dry cloth.
- Do not use any abrasive cleaning tools such as steel wool, scouring sponges or stiff brushes.
- Never use strong cleaning agents such as white spirit, turpentine, household glass cleaner or cellulose thinners.


&Tradition will not accept any responsibility for any accidents or injuries that occur due to incorrect USB cable input. The battery must be removed from the light before it is scrapped; the appliance must be disconnected from the supply mains when removing the battery; the battery must be disposed of safely.

For further information or inquiries, please do not hesitate to contact &Tradition by mail on [info@andtradition.com](mailto:info@andtradition.com).

For indoor use  
Input 5.0V === 2A cable  
G4 Max 3 Watt dimmable LED bulb  
2 × Rechargeable &Tradition batteries


Charging time: 16 hours

Operating time on highest setting: 20 hours




## Step 1

Remove plastic slip to activate the battery. You do not need to open the battery compartment.



## Step 2

Insert the LED light bulb. Carefully lower the shade onto the base and turn clockwise to install. Make sure to turn the shade until it cannot be turned anymore, whereby the shade will be turned 45 degrees.



## Step 3


Before use, the battery in the lamp needs to be charged. Plug the magnetic USB cable into the bottom of the base and connect the USB cable to a power supply.



## Replacing batteries


### Step 1

To replace the batteries, start by removing the pad underneath and unscrew the four screws. Remove the battery compartment from the lamp exterior.



### Step 2

Unscrew the screw in the battery compartment by turning anticlockwise and remove the lid.



### Step 3

Take out the batteries and replace it with new batteries. Correctly place the batteries by turning the plus and minus pole as stated in the battery compartment.

**Be sure to mount the lid gently by not overturning the screw in the threading.**

Remember to only use official rechargeable batteries from &Tradition.

